

American Ballast Model Nomenclature Key
Last Modified: 5-9-2005

AB **X** - **XX** - **X** **X** - **XXX** - **XXX**

1, 2 **3** - **4, 5** - **6** **7** - **8, 9, 10** - **11, 12, 13**

- AB** American Ballast, Always Used
- 3** Primary Lamp Count Design Indicator (1-4)
- 4-5** Primary Lamp Design Rated Watts (8, 15, 32 etc.)
- 6** Starting Method Indicator
 - I: Instant Start
 - P: Program Start
 - R: Rapid Start
- 7** Ballast Wiring Method
 - P: Parallel Wired Ballast
 - S: Series Wired Ballast
- 8-10** Primary Voltage Design Rating (120, 277, 347, UNV)

******INTERNAL KEY THAT WILL BE UPDATED REGULARLY******

11-13 Suffix for Design Change Indication (Optionally Applied)

- LP: Low Power, 78 Ballast Factor
- HP: High Power, 1.18 Ballast Factor
- HX: High Power, 1.30 Ballast Factor
- HE: High Efficiency
- R: Residential
- C: Combination Residential & Commercial
- 3 THD< 30%
- 1 THD< 10%
- S Slim series